

ASSEMBLY INSTRUCTIONS CORFU BUNK BED



IMPORTANT: READ THIS INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR CORFU BUNK BED FRAME.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH & SAFETY:

DO NOT jump on this bed frame.

DO NOT use this bed frame if any parts are missing, damaged or worn.

DO NOT use this bed frame unless all fixings are secured.

Please keep small parts out of reach of children.

Always use on a level, even surface.

Be aware of the danger of young children (under 6) falling from the upper bunk. It is not suitable for children under the age 6 to sleep on the top bunk.

This bed frame complies to BS EN 747 1&2:2012 + A1:2015

Always follow the manufacturer's instructions.

CAUTION: There is the risk of strangulation to children from items such as string, ropes, cords, harnesses and belts hanging from the bed frame.

WARNING: Children can become trapped between the bed and the wall. To avoid risk of serious injuries the distance between the top safety barrier and the adjoining structure shall not exceed 75mm or shall be more than 230mm.

WARNING: If this bed is placed on a non-carpeted floor you must place some protection under all legs to stop the bed from moving. If this is not adhered to there is no guarantee if the bed frame collapses.

CARE & MAINTENANCE:

Assemble in the room of use.

Periodically check all screws & fixings to ensure they are secure.

DO NOT push the bed frame as this will damage the legs.

Always lift the bed with two people to reposition.

Keep any sharp objects away from the frame.

Recommended size of mattress is 3ft x 6ft 3inch.

Sticker marking the mattress maximum thickness can be found on the headboard post and mattress being used do not exceed the arrow on the sticker.

Recommended maximum mattress height for top bunk is 200mm.

Recommended maximum mattress height for bottom bunk is 150mm.

Ventilation of the room is necessary in order to keep the humidity low and to prevent mold in and around the bed.






Part List				Hardware List (found in box 2)			
Part	Description	Вох	Qty	Part	Description		Qty
1	Upper Frame	1	2	Α	M8 Metal Square Nut	OTEN	8
2	Bottom Frame	1	2	В	M8 x 95mm JCBC Screw	9	8
3	Bottom Base	2	1	С	M6 x 45mm JCBC Screw	0	8
4	Top Base	2	1	D	M6 x 15mm JCN Nut	⊗	8
5	Back Rail	2	1	E	M6 x 80mm JCBC Screw	0	9
6	Front Rail	2	1	F	M6 x 35mm JCBC Screw	9	2
7	Ladder	2	1	G	M6 x 16mm JCBC Screw	9	2
8	Frame Connector	1	4	н	50mm Black Round Stopper		4
**M4 Allen Key & M5 Allen Key provided				Ĺ	50mm Beige Round Cap		4
				J	Black Round Stud	8	6


Step 1: Insert hardware part (H) to the Bottom Frame (2) then slot the Bottom Base (3) into the brackets on the Bottom Frame. Place the Frame Connector (8) onto the Bottom Frame then insert the Upper Frames (1) by facing hole to hole as shown in views **AA**.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Page 2 of 5

Step 2: Secure the Frame Connectors (8) using hardware parts (C) and (D) for the bedposts as shown in view **AA**. **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




Step 3: Slot the Top Base (4) into the brackets on the Upper Frame (1) and secure using hardware parts (A) and (B) at the four corners. Then secure the Bottom Base (3) using hardware parts (A) and (B) at the four corners but do not tighten the screws yet.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.





Step 4: Secure the horizontal tube of the Back Rail (5) to the Upper Frame (1), then secure the Back Rail to the Top Base (4) using hardware part (E).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




DO NOT use any power tools as this may damage the frame and will invalidate any claim.






Step 6: Assemble the Ladder (7) using hardware parts (F) & (G). **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




Step 7: Insert hardware part (I) onto the Upper Frame (1).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



Step 8: Insert hardware part (J) into the extra 10mm holes. **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**



Additional Information:

- For complete product information, images and dimension diagrams please visit the website www.birlea.com.
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on instagram.

