

Assembly Instructions

Thank you for purchasing a **Birlea** product.

For a chance to win a *Love 2 Shop* voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture and using the hashtag **#ShareYourStyle** and **#Birlea**. One winner will be selected at random each month.

To view our full terms and conditions please visit our website. www.birlea.com

Are you happy with your purchase?

- Yes: That's great, we would love to hear more from you. Please leave us a review on our social media channels or Trustpilot. Your feedback will be greatly appreciated.
- *No:* If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer you purchased the item from. We will work with the retailer to resolve your issue as quickly as possible.



ASSEMBLY INSTRUCTIONS MERLIN HIGH SLEEPER

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR MERLIN HIGH SLEEPER FRAME.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

HEALTH & SAFETY:

DO NOT jump on this bed frame. DO NOT use this bed frame if any parts are missing, damage or worn. DO NOT use this bed frame unless all fixings are secured. Please keep small parts out of reach of children. Always use on a level, even surface. This bed is tested to European safety standard BS EN 747-1 & 2:2012+4I:2015

WARNING: If this bed is placed on a non-carpeted floor you must place some protection under all legs to stop the bed frame from moving. If this is not adhered to there is no guarantee if the bed frame collapses.

WARNING: High beds are not suitable for use by children under 6 years of age due to risk of injury from falls.

WARNING: Please note the area underneath the bed is to used for storage purpose only

WARNING: High beds present a serious risk of injury from strangulation if used incorrectly. Never attach or hang anything on any part of the frame that is not designed to be used with the bed, for example, but not limited to ropes, strings, cords, hooks, belts, and bags.

WARNING: Do not use the high bed if any structural part is missing or broken.

WARNING: Children can become trapped between the bed and adjoining structures including walls, roof pitches, ceilings and other pieces of furniture. To avoid risk of serious injury, the distance between the top safety barrier and any adjoining structure shall not exceed 75mm or shall be more than 230mm.

CARE & MAINTENANCE:

Assemble in the room of use.

Assemble on a soft, clean surface.

Please check regularly that all assembly fastening are properly tightened.

DO NOT push the bed frame as this will damage the legs.

Always lift the bed with two people to reposition.


Use a soft, dry cloth to clean - do not use any detergents or chemicals.

Avoid contact with water and direct sunlight. Do not place bed near heat sources, window to keep the humidity low and prevent mould in and around the bed

INFORMATION


- Maximum thickness of mattress 15cm. Please refer to making headboard.
- Recommend size of mattress L192cm x W92cm x H15cm
- When you are ready to start, make sure that you have the right tools, plenty of space on a clean, dry area for assembly.
- Check the pack and make sure you have all the part listed.
- Ensure that this product is fully assembly and secured as illustrated before use.







	RTS LIST			RDWARE LIST: Cartor	<u>1 2 of 3</u>	
Carton 1 of 4:			Part	Description		Qty
Part	Description	Qty	Α	CAM NUT 15mm		4
3	Back Side Panel	1	В	CAM BOLT	OTIEND	4
4	Back Base Panel	1	С	WOOD DOWEL M8 x 30mm		47
5	Front Base Panel	1	D	JCBC SCREW M6 x 50mm	Orninno	10
8	Base Bottom Support Panel	1	E	M6 STEEL NUT	60	10
Carton 2 of 4:			F	M6 x 40mm UNITAR SCREW	Octomore	60
	Description	Qty	G	CSK SCREW M4 x 38mm	Gannant	4
1	Left Side Panel	1	Н	CSK SCREW M4 x 25mm	() and the second secon	2
2	Right Side Panel	1	Ι	CSK SCREW M4 x 16mm	Same.	30
30	Drawer Bottom Panel	1	J	CSK SCREW M4 x 12mm	Barra	16
31	Table Back Panel	1	K	PVC FEET NAIL	R	14
32		1	L	NAIL		8
	-		М	METAL SHELF SUPPORT	ක	4
	ion 3 of 4:		N	VK-43 ALUMINIUM BRACKET	Ø	2
	Description	Qty	0	OVAL PIPE 573mm		1
9	Left Panel	1	Р	DOOR STOPPER	Ø	2
10	0	1	Q	MDF SUPPORT	P	4
11		3	R	METAL L-BRACKET		3
12	11	3	S	HINGES ⁷ / ₈ "	þ.	3
13		3	Т	METAL RUNNER TRUCK 14"		1se ⁻
14	Cabinet Bottom Panel	1				
15		1	U	METAL RUNNER 14"		1se
16		1	V	ALLEN KEY		1
17	Support Panel	1	W	STICKER	\bigcirc	17
21		1	Х	HOLE CAP 35mm	Ø	1
22		1	L			1
23		1				
25		1		** WARNING: THE	USE OF	
-	Drawer Front Panel	1		POWER TOOLS TO		1BLE
27		1		THIS PRODUCT W	/ILL	
28	Drawer Left Panel	1		INVALIDATE ANY		
29	Drawer Right Panel	1	-	MAY DAMAGE THI		JCT
33		1		MAKING IT UNSAF	E.	
	Hardware List					
Car	on 4 of 4:		** Yo	ou will need a screwdriver and a s	mall malle	et
	Description	Qty		T provided)		
6	Left Front Side Panel	1				
7	Right Front Side Panel	1				
18	Door	1				
19	Table Top	1				
20	Table Back Panel	1				
24	Movable Panel	1				










F





Attach the ladder bottom support panel (12) and ladder step panel (13) to the right panel (10) with screw (F) by using allen key (V) and tighten clockwise.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Page 6 of 25







Attach cabinet back support panel (16) to left panel (9) with screw (F) by using allen key (V) and tighten clockwise. Attach cabinet plinth panel (15) and (33) to left panel (9). **DO NOT** use any power tools as this may damage the frame and will invalidate any claim.








Attach cabinet bottom panel (14) to left panel (9) with screw (F) by using allen key (V) and tighten clockwise.













Attach right side panel (2) with screw (D) & screw (F) by using allen key (V) and tighten clockwise.







Suppliers of inspiration

Attach cabinet back panel (32) with screw (J) using a screwdriver (not provided) and nail (L) by using small mallet (not provided).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Page 13 of 25








Fix back side panel (3) with screw (D) & hardware (E) by using allen key (V) and tighten clockwise.









Suppliers of inspiration


Page 16 of 25



Attach left and right front side panels (6) & (7) with screw (D) and hardware (E) by using allen key (V) and tighten clockwise.


Fix hardware (R) with screw (I) by using screwdriver (not provided).






Fix left and right front side panels (6) & (7) with screw (F) by using allen key (V) and tighten clockwise.

Insert hanger pipe (O) and hardware (M) as shown.













Fix drawer left & right panels (28) & (29) to drawer back panel (27) with screw (G) by screwdriver (not provided).


 $\ensuremath{\text{DO NOT}}$ use any power tools as this may damage the frame and will invalidate any claim.











Your **MERLIN HIGH SLEEPER** is now completely assembled.

Periodically check to ensure that the components are in their proper postition, free from damage. Also, make sure the connectors are tight and secure.

